

Challenger Door

Pet Guard Installation Guide

Date: 7/28/20

BY:AWY

Tools Needed

- screw gun
- #2 square drive bit
- 3/16" drill bit



1. Determine the location desired on your screen door to install your pet guard.
2. Mark where the mounting holes need to be located on the cross bars.
3. Drill 3/16" holes where marked in all 4 corners.
****Do Not drill into the screen door frame****
4. Using the screws provided, install the Pet Guard at the desired location.

